

Introduction to SONiC-OTN RESTCONF and TELEMETRY


Alibaba Cloud
Xin Lei (leixin.lei@alibaba-inc.com)

SONiC-OTN Management Framework Overview



Management Framework consists of the following components:

- REST Server – a HTTP server implemented in Go language supports RESTCONF APIs for YANG data.
- Telemetry Dialout Client – a service implemented in Go language supports gNMI dialout publish
- Translib – a library that adapts requests from REST server to SONiC data providers and vice versa.
- Multi-DB – introduced it the last meeting




*SONiC-OTN Management Framework
Abstract Diagram*

Management Framework Arch



Translib consists of three parts:


- Message Conversion
 - Request Handler:
The APIs support to convert the incoming path and payload from the request into YGOT structures.
 - YGOT Request Binder:
Generate a set of Go structures for the given YANG modules at build time and Unmarshall the given request into the Go structure objects.
- Data Translation
 - App Modules:
Translate YGOT structures to DB schema and vice versa.
 - Transformer: A way to translate data automatically.
- DB Operation:
 - DB Access Layer: CRUD APIs in Go language
 - CVL: Validate configuration data before it is written to DB



Management Framework architecture

REST Set Flow


The flow of Management Framework for Turning on the laser :



REST Get Flow



The flow of Management Framework for querying the laser value of the transceiver:




Multiple Databases Strategy



- Name different components by a fixed rule
- Derive two new type in DB Access Layer
 - `type MDB map[string][MaxDB]*DB`
 - `type NumberDB map[string]*DB`
- Extend App Interface with several interfaces
- Bind the new interfaces to TransLib request handlers

[ComponentType]-[ChassisID]-[SlotID]-[PortName / Number]
Without slot: CHASSIS-1、CU-1
Without port: FAN-1-7、PSU-1-5、LINECARD-1-2
Port name: OCH-1-3-L1、TRANSCEIVER-1-1-C1、PORT-1-4-OLPPRIIN
Number: AMPLIFIER-1-4-1、APS-1-4-1、OSC-1-4-1

```
translateMDBReplace(numDB db.NumberDB)
processMDBReplace(numDB db.NumberDB)
translateMDBGet(mdb db.MDB)
processMDBGet(mdb db.MDB)
// used by Telemetry
translateGetRegex(mdb db.MDB)
processGetRegex(mdb db.MDB)
```



Database Modeling

openconfig-optical-amplifier	module
optical-amplifier	container
amplifiers	container
amplifier[name]	list
name	leaf
config	container
name	leaf
type	leaf
target-gain	leaf
min-gain	leaf
max-gain	leaf
target-gain-tilt	leaf
gain-range	leaf
amp-mode	leaf
target-output-power	leaf
max-output-power	leaf
enabled	leaf
fiber-type-profile	leaf
state	container
name	leaf
type	leaf
target-gain	leaf
min-gain	leaf
max-gain	leaf
target-gain-tilt	leaf
gain-range	leaf
amp-mode	leaf
target-output-power	leaf
max-output-power	leaf
enabled	leaf
fiber-type-profile	leaf
component	leaf
ingress-port	leaf
egress-port	leaf
actual-gain	container
instant	leaf
avg	leaf
min	leaf
max	leaf
interval	leaf
min-time	leaf
max-time	leaf
actual-gain-tilt	container
input-power-total	container
input-power-c-band	container
input-power-l-band	container
output-power-total	container
output-power-c-band	container
output-power-l-band	container
laser-bias-current	container
optical-return-loss	container



DATABASE	TABLE	FIELD
CONFIG_DB	AMPLIFIER AMPLIFIER-1-4-1	name
		type
		target-gain
		min-gain
		max-gain
		target-gain-tilt
		gain-range
		amp-mode
		target-output-power
		max-output-power
		enabled
		fiber-type-profile
		name
STATE_DB	AMPLIFIER AMPLIFIER-1-4-1	type
		target-gain
		min-gain
		max-gain
		target-gain-tilt
		gain-range
		amp-mode
		target-output-power
		max-output-power
		enabled
		fiber-type-profile
		component
		ingress-port
COUNTERS_DB	AMPLIFIER:AMPLIFIER-1-4-1_ActualGain:15_pm_current	egress-port
		instant
		avg
		min
		max
		interval
		min-time
		max-time
		starttime
		validity

- Leaf node must have a field of the same name in database
- List node must have a table in database
- Container node for a gauge value must have a table in database, and other Container nodes may have a table or not

Object-oriented approach of App Modules

Simplify the implementation of App Modules in two stages:


1. Automatic data translation for CONTAINER nodes ---- (supported)
 - LEAF node is an object named *GoStructField*
 - CONTAINER node is an object named *GoStruct*
2. Automatic data translation for one YANG model ---- (future)
 - Traverse YANG tree by depth-first search
 - Get the mapped DB info of YANG nodes automatically



YANG Model Driven In SONiC can be TRUE ?


Current Situation:

- Step 1: All leaf nodes were built automatically, but the mapping between YANG and DB schema was written manually
- Step 2: A set of buildXXX functions which represent the hierarchy of YANG models were written manually




Dial-out Client With OpenConfig YANG


- Data Collectors: receive the gNMI data from Dial-out Client
- Dial-out Client: publish the subscribed data periodically or it was changed
- TransL Data Client: execute subscriptions and translate the JSON data from TransL Utils to gNMI format
- TransL Utils: a set of APIs to invoke Translib, then parse the payload returned by Translib to JSON format
- Subscriptions managed by OpenConfig Telemetry Module



SAMPLE Subscribe-Publish Flow



ONCHANGE Subscribe-Publish Flow



Custom Functionalities in Dial-out Client



- sensor-path without key
- data aggregation for sensor-path without key
- data filtering support to publish PM data only

```
.. "sensor-group-id": "och_sensor_group",
.. "config": {
..   "sensor-group-id": "och_sensor_group"
.. },
.. "sensor-paths": {
..   "sensor-path": [
..     {
..       "path": "/openconfig-platform:components/component/
..         openconfig-terminal-device:optical-channel/state",
..       "config": {
..         "path": "/openconfig-platform:components/component/
..           openconfig-terminal-device:optical-channel/state"
..       }
..     }
..   ]
.. }
```

```
▼ fullContent: {}
▼ update: {}
  timestamp: "1681795812981484033"
  prefix: {}
    origin: "TBC04-K-BA-T008"
    target: "OC-YANG"
  update: []
  {}
  path: {}
    elem: []
    {}
      name: "openconfig-interfaces:interfaces"
    {}
      name: "interface"
      key: {}
        name: "INTERFACE-1-1-C1"
    {}
      name: "state"
    {}
      name: "counters"
  val: {}
  jsonVal: {}
    in-broadcast-pkts: 0
    in-multicast-pkts: 0
    in-octets: 1954052689028752
    in-pkts: 2860386613942
    out-broadcast-pkts: 0
    out-multicast-pkts: 0
    out-octets: 394932905060786
    out-pkts: 578111704195
  {}
  path: {}
    elem: []
    {}
      name: "openconfig-interfaces:interfaces"
    {}
      name: "interface"
      key: {}
        name: "INTERFACE-1-1-C4"
    {}
      name: "state"
    {}
      name: "counters"
  val: {}
  jsonVal: {}
    in-broadcast-pkts: 0
    in-multicast-pkts: 0
    in-octets: 491299806004930
    in-pkts: 719175790754
    out-broadcast-pkts: 0
    out-multicast-pkts: 0
    out-octets: 407868277406234
    out-pkts: 597046815923
```

```
▼ fullContent: {}
▼ update: {}
  timestamp: "1681795812629116160"
  prefix: {}
    origin: "TBC04-K-BA-T008"
    target: "OC-YANG"
  update: []
  {}
  path: {}
    elem: []
    {}
      name: "openconfig-platform:components"
    {}
      name: "component"
      key: {}
        name: "OCH-1-1-L2"
    {}
      name: "openconfig-terminal-device:optical-channel"
    {}
      name: "state"
  val: {}
  jsonVal: {}
    actual-frequency-offset: 570
    chromatic-dispersion: {}
      avg: 4
      instant: 4
      interval: 900000000000
      max: 4
      max-time: 1681795800817667790
      min: 4
      min-time: 1681795800817667790
    input-power: {}
      avg: -0.81
      instant: -0.83
      interval: 900000000000
      max: -0.8
      max-time: 1681795804492181885
      min: -0.83
      min-time: 1681795809493981383
    laser-bias-current: {}
      avg: 244
      instant: 244
      interval: 900000000000
      max: 244
      max-time: 1681795800817667790
      min: 244
      min-time: 1681795800817667790
    osnr: {}
      avg: 34.46
      instant: 34.1
      interval: 900000000000
      max: 34.6
```

Q & A